








A  1PC

1







1. Align the back cushion with the seat cushion frame as shown in the picture.
2. Align and connect the linking hook of the back cushion with slot "C" on the seat cushion frame.
3. Straighten the back cushion, then press the back cushion downwards to connect the bottom of the back cushion frame with the seat cushion frame, at points "D".
4. Screw the bolt tightly at joint "B" under the seat cushion. Ensure that the bolt is completely tightened.

2




Shaken the back cushion in every direction (backwards, forwards and upwards) to ensure the back cushion is securely locked onto the seat cushion frame.

3







Connect the power and recline the backrest slightly.

4



Zip up the gap between seat and backrest.

5



# How to adjust the headrest

P4



To adjust the headrest, grip the backside of the headrest and pull forward from both sides as shown



DO NOT pull from the side edges, as the material may tear



To adjust the headrest backward, push on both sides or use a forearm to evenly move the headrest

Caution:

Do not push in the center of the headrest, as this may cause the cushion to collapse

